

TARIF CONSOMMABLES OKI

Juin 2022

Référence	Désignation	Prix Partenaire	TVA %
01103402	Toner OKI Noir B4100-B4200-B4300 (3K)	170	19
01173201	Récupérateur de toner usagé ES3640-ES9410-Pro9420 (30K)	82	19
01221701	Tambour OKI B930 (60K)	1178	19
01247401	Tambour OKI Jaune ES8430-ES8460-ES8451-ES8461 (20k)	438	19
01247402	Tambour OKI Magenta ES8430-ES8460-ES8451-ES8461 (20k)	438	19
01247403	Tambour OKI Cyan ES8430-ES8460-ES8451-ES8461 (20k)	438	19
01247404	Tambour OKI Noir ES8430-ES8460-ES8451-ES8461 (20k)	344	19
01249001	Tambour OKI Noir ES4140-ES4160-ES4180 (25K)	525	19
01254401	Toner OKI Noir ES9130 (30K)	432	19
01260701	Tambour OKI Noir ES9130 (60K)	880	19
01262101	Toner OKI Noir ES6150 (17K)	879	19
01272901	Tambour OKI Jaune ES6410 (20K)	414	19
01272902	Tambour OKI Magenta ES6410 (20K)	417	19
01272903	Tambour OKI Cyan ES6410 (20K)	417	19
01272904	Tambour OKI Noir ES6410 (20K)	231	19
01279001	Toner OKI Noir B710-B720-B730 (15K)	986	19
01279101	Toner OKI Noir B720 (20K)	1082	19
01279201	Toner OKI Noir B730 (25K)	1179	19
01279301	Toner OKI Noir ES7120-ES7130 (25K)	972	19
01282901	Tambour OKI Noir ES5430-ES5451-ES5461 (20K)	422	19
01282903	Tambour OKI ES5431-ES5452-ES5462 (20K)	587	19
01283601	Tambour OKI ES4131-ES4132-ES4161-ES4191 (25K)	435	19
01310001	Toner OKI ES8140 (20K)	793	19
01333301	Tambour OKI Jaune ES7460-ES7480 (30K)	426	19
01333302	Tambour OKI Magenta ES7460-ES7480 (30K)	426	19
01333303	Tambour OKI Cyan ES7460-ES7480 (30K)	426	19

01333304	Tambour OKI Noir ES7460-ES7480 (30K)	422	19
09006127	Toner OKI Cyan C650 (6K)	355	19
09006128	Toner OKI Magenta C650 (6K)	355	19
09006129	Toner OKI Jaune C650 (6K)	355	19
09006130	Toner OKI Noir C650 (7K)	296	19
09006131	Tambour OKI Noir C650 (50K)	470	19
09006132	Tambour OKI Cyan C650 (50K)	470	19
09006133	Tambour OKI Magenta C650 (50K)	470	19
09006134	Tambour OKI Jaune C650 (50K)	470	19
42869403	Récupérateur de toner usagé C910-C920-C9600-9800 (30K)	59	19
42918105	Tambour OKI Jaune C9600-C9800-C9650-C9850 (30K)	759	19
42918106	Tambour OKI Magenta C9600-C9800-C9650-C9850 (30K)	759	19
42918107	Tambour OKI Cyan C9600-C9800-C9650-C9850 (30K)	759	19
42918108	Tambour OKI Noir C9600-C9800-C9650-C9850 (30K)	759	19
42918121	Tambour OKI Jaune ES3640 (30K)	679	19
42918122	Tambour OKI Magenta ES3640 (30K)	679	19
42918123	Tambour OKI Cyan ES3640 (30K)	679	19
42918124	Tambour OKI Noir ES3640 (30K)	432	19
42918181	Tambour OKI Jaune ES3640a3 (30K)	803	19
42918182	Tambour OKI Magenta ES3640a3 (30K)	803	19
42918183	Tambour OKI Cyan ES3640a3 (30K)	803	19
42918184	Tambour OKI Noir ES3640a3 (30K)	514	19
42918913	Toner OKI Jaune C9600-C9800-C9650-C9850 (15K)	1586	19
42918914	Toner OKI Magenta C9600-C9800-C9650-C9850 (15K)	1586	19
42918915	Toner OKI Cyan C9600-C9800-C9650-C9850 (15K)	1586	19
42918916	Toner OKI Noir C9600-C9800-C9650-C9850 (15K)	694	19
42918925	Toner OKI Jaune ES3640 (15K)	968	19
42918926	Toner OKI Magenta ES3640 (15K)	968	19
42918927	Toner OKI Cyan ES3640 (15K)	968	19
42918928	Toner OKI Noir ES3640 (15K)	260	19
42918961	Toner OKI Jaune C9600-C9800-C9650-C9850 (15K)	1586	19
42918962	Toner OKI Magenta C9600-C9800-C9650-C9850 (15K)	1586	19
42918963	Toner OKI Cyan C9600-C9800-C9650-C9850 (15K)	1586	19

42918964	Toner OKI Noir C9600-C9800-C9650-C9850 (15K)	694	19
43324408	Toner OKI Noir C5600-C5700 (6K)	391	19
43324421	Toner OKI Jaune C5800-C5900 (5K)	714	19
43324422	Toner OKI Magenta C5800-C5900 (5K)	714	19
43324423	Toner OKI Cyan C5800-C5900 (5K)	714	19
43324424	Toner OKI Noir C5800-C5900 (6K)	391	19
43324440	Toner OKI Noir C5600-C5700 (6K)	391	19
43324441	Toner OKI Jaune C5800-C5900 (5K)	714	19
43324442	Toner OKI Magenta C5800-C5900 (5K)	714	19
43324443	Toner OKI Cyan C5800-5900 (5K)	714	19
43324444	Toner OKI Noir C5800-C5900 (6K)	391	19
43381705	Tambour OKI Jaune C5700 (20K)	307	19
43381706	Tambour OKI Magenta C5700 (20K)	307	19
43381707	Tambour OKI Cyan C5700 (20K)	307	19
43381708	Tambour OKI Noir C5700 (20K)	307	19
43381721	Tambour OKI Jaune C5800-C5900 (20K)	307	19
43381722	Tambour OKI Magenta C5800-C5900 (20K)	307	19
43381723	Tambour OKI Cyan C5800-C5900 (20K)	307	19
43381724	Tambour OKI Noir C5800-C5900 (20K)	307	19
43381905	Toner OKI Jaune C5600-C5700 (2K)	358	19
43381906	Toner OKI Magenta C5600-C5700 (2K)	358	19
43381907	Toner OKI Cyan C5600-C5700 (2K)	358	19
43381921	Toner OKI Jaune C5600-C5700 (2K)	358	19
43381922	Toner OKI Magenta C5600-C5700 (2K)	358	19
43381923	Toner OKI Cyan C5600-C5700 (2K)	358	19
43459436	Toner OKI Noir C3300-C3400-C3450-C3600 (1.5K)	190	19
43460205	Tambour OKI Jaune C3300-C3400-C3450-C3600 (15K)	186	19
43460206	Tambour OKI Magenta C3300-C3400-C3450-C3600 (15K)	186	19
43460207	Tambour OKI Cyan C3300-C3400-C3450-C3600 (15K)	186	19
43460208	Tambour OKI Noir C3300-C3400-C3450-C3600 (15K)	186	19
43837105	Toner OKI Jaune ES3640Pro (16.5K)	987	19
43837106	Toner OKI Magenta ES3640Pro (16.5K)	987	19
43837107	Toner OKI Cyan ES3640Pro (16.5K)	987	19

43837108	Toner OKI Noir ES3640Pro (18.5K)	240	19
43837129	Toner OKI Jaune C9655 (20K)	1564	19
43837130	Toner OKI Magenta C9655 (20K)	1564	19
43837131	Toner OKI Cyan C9655 (20K)	1564	19
43837132	Toner OKI Noir C9655 (22.5K)	697	19
43837133	Toner OKI Jaune C9655 (20K)	1564	19
43837134	Toner OKI Magenta C9655 (20K)	1564	19
43837135	Toner OKI Cyan C9655 (20K)	1564	19
43837136	Toner OKI Noir C9655 (22.5K)	697	19
43865708	Toner OKI Noir C5650-C5750 (8K)	488	19
43865721	Toner OKI Jaune C5850-C5950 (6K)	811	19
43865722	Toner OKI Magenta C5850-C5950 (6K)	811	19
43865723	Toner OKI Cyan C5850-C5950 (6K)	811	19
43865724	Toner OKI Noir C5850-C5950 (8K)	488	19
43865740	Toner OKI Noir C5650-C5750 (8K)	488	19
43865741	Toner OKI Jaune C5850-C5950 (6K)	811	19
43865742	Toner OKI Magenta C5850-C5950 (6K)	811	19
43865743	Toner OKI Cyan C5850-C5950 (6K)	811	19
43865744	Toner OKI Noir C5850-C5950 (8K)	488	19
43870005	Tambour OKI Jaune C5650-C5750 (20K)	307	19
43870006	Tambour OKI Magenta C5650-C5750 (20K)	307	19
43870007	Tambour OKI Cyan C5650-C5750 (20K)	307	19
43870008	Tambour OKI Noir C5650-C5750 (20K)	307	19
43870021	Tambour OKI Jaune C5850-C5950-MC560 (20K)	267	19
43870022	Tambour OKI Magenta C5850-C5950-MC560 (20K)	267	19
43870023	Tambour OKI Cyan C5850-5950-MC560 (20K)	267	19
43870024	Tambour OKI Noir C5850-C5950-MC560 (20K)	267	19
43872305	Toner OKI Jaune C5650-C5750 (2K)	358	19
43872306	Toner OKI Magenta C5650-C5750 (2K)	358	19
43872307	Toner OKI Cyan C5650-C5750 (2K)	358	19
43872321	Toner OKI Jaune C5650-C5750 (2K)	358	19
43872322	Toner OKI Magenta C5650-C5750 (2K)	358	19
43872323	Toner OKI Cyan C5650-C5750 (2K)	358	19

43913805	Tambour OKI Jaune C710 (15K)	529	19
43913806	Tambour OKI Magenta C710 (15K)	529	19
43913807	Tambour OKI Cyan C710 (15K)	529	19
43913808	Tambour OKI Noir C710 (20K)	317	19
43979002	Tambour OKI Noir B410-B430-B440-MB460 (25K)	627	19
43979102	Toner OKI Noir B410-B430-B440 (3.5K)	184	19
43979107	Toner OKI Noir B410-B430-B440 (3.5K)	184	19
43979202	Toner OKI Noir B430-B440 (7K)	450	19
43979211	Toner OKI Noir B430-B440 (7K)	450	19
43979223	Toner OKI Noir ES4160-ES4180-ES4140 (12K)	293	19
44035517	Tambour OKI Jaune C910-C920 (20K)	1061	19
44035518	Tambour OKI Magenta C910-C920 (20K)	1061	19
44035519	Tambour OKI Cyan C910-C920 (20K)	1061	19
44035520	Tambour OKI Noir C910-C920 (20K)	645	19
44035521	Tambour OKI Jaune ES9410-ES9420WT (20K)	736	19
44035522	Tambour OKI Magenta ES9410-ES9420WT (20K)	736	19
44035523	Tambour OKI Cyan ES9410-ES9420WT (20K)	736	19
44035524	Tambour OKI Noir ES9410-ES9420WT (20K)	506	19
44035547	Tambour OKI Blanc C920WT (10K)	679	19
44035548	Tambour OKI Blanc PRO9420WT (10K)	639	19
44036021	Toner OKI Jaune C910-C920 (15K)	665	19
44036022	Toner OKI Magenta C910-C920 (15K)	677	19
44036023	Toner OKI Cyan C910-C920 (15K)	665	19
44036024	Toner OKI Noir C910-C920 (15K)	292	19
44036025	Toner OKI Jaune ES9410-ES9420WT (15K)	484	19
44036026	Toner OKI Magenta ES9410-ES9420WT (15K)	484	19
44036027	Toner OKI Cyan ES9410-ES9420WT (15K)	484	19
44036028	Toner OKI Noir ES9410 (15K)	237	19
44036059	Toner OKI Blanc C920WT (8K)	1406	19
44036060	Toner OKI Blanc PRO9420WT (8K)	1321	19
44059105	Toner OKI Jaune C810-C830 (8K)	831	19
44059106	Toner OKI Magenta C810-C830 (8K)	831	19
44059107	Toner OKI Cyan C810-C830 (8K)	831	19

44059108	Toner OKI Noir C810-C830 (8K)	345	19
44059117	Toner OKI Jaune C810-C830 (8K)	831	19
44059118	Toner OKI Magenta C810-C830 (8K)	831	19
44059119	Toner OKI Cyan C810-C830 (8K)	831	19
44059120	Toner OKI Noir C810-C830 (8K)	345	19
44059125	Toner OKI Jaune ES8430 (7K)	549	19
44059126	Toner OKI Magenta ES8430 (7K)	549	19
44059127	Toner OKI Cyan ES8430 (7K)	549	19
44059128	Toner OKI Noir ES8430 (7.5K)	325	19
44059165	Toner OKI Jaune MC851-MC861 (7.3K)	575	19
44059166	Toner OKI Magenta MC851-MC861 (7.3K)	575	19
44059167	Toner OKI Cyan MC851-MC861 (7.3K)	575	19
44059168	Toner OKI Noir MC851-MC861 (7K)	250	19
44059169	Toner OKI Jaune MC851-MC861 (7.3K)	575	19
44059170	Toner OKI Magenta MC851-MC861 (7.3K)	575	19
44059171	Toner OKI Cyan MC851-MC861 (7.3K)	575	19
44059172	Toner OKI Noir MC851-MC861 (7K)	250	19
44059209	Toner OKI Jaune MC860 (10K)	954	19
44059210	Toner OKI Magenta MC860 (10K)	954	19
44059211	Toner OKI Cyan MC860 (10K)	954	19
44059212	Toner OKI Noir MC860 (9.5K)	355	19
44059225	Toner OKI Jaune MC860 (10K)	954	19
44059226	Toner OKI Magenta MC860 (10K)	954	19
44059227	Toner OKI Cyan MC860 (10K)	954	19
44059228	Toner OKI Noir MC860 (9.5K)	355	19
44059229	Toner OKI Jaune ES8460 (9K)	573	19
44059230	Toner OKI Magenta ES8460 (9K)	573	19
44059231	Toner OKI Cyan ES8460 (9K)	573	19
44059232	Toner OKI Noir ES8460 (9K)	183	19
44059253	Toner OKI Jaune MC861 (10K)	706	19
44059254	Toner OKI Magenta MC861 (10K)	706	19
44059255	Toner OKI Cyan MC861 (10K)	705	19
44059256	Toner OKI Noir MC861 (9.5K)	287	19

44059257	Toner OKI Jaune ES8451-ES8461 (9K)	382	19
44059258	Toner OKI Magenta ES8451-ES8461 (9K)	382	19
44059259	Toner OKI Cyan ES8451-ES8461 (9K)	382	19
44059260	Toner OKI Noir ES8451-ES8461 (9K)	115	19
44059261	Toner OKI Jaune MC861 (10K)	706	19
44059262	Toner OKI Magenta MC861 (10K)	706	19
44059263	Toner OKI Cyan MC861 (10K)	705	19
44059264	Toner OKI Noir MC861 (10K)	287	19
44064009	Tambour OKI Jaune C801-C810-C821-C830-MC860-MC851-MC861 (20K)	548	19
44064010	Tambour OKI Magenta C801-C810-C821-C830-MC860-MC851-MC861 (20K)	548	19
44064011	Tambour OKI Cyan C801-C810-C821-C830-MC860-MC851-MC861 (20K)	548	19
44064012	Tambour OKI Noir C801-C810-C821-C830-MC860-MC851-MC861 (20K)	548	19
44315105	Tambour OKI Jaune C610 (20K)	341	19
44315106	Tambour OKI Magenta C610 (20K)	341	19
44315107	Tambour OKI Cyan C610 (20K)	341	19
44315108	Tambour OKI Noir C610 (20K)	307	19
44315305	Tambour OKI Jaune C610 (20K)	774	19
44315306	Tambour OKI Magenta C610 (20K)	774	19
44315307	Tambour OKI Cyan C610 (20K)	774	19
44315308	Tambour OKI Noir C610 (20K)	464	19
44315317	Toner OKI Jaune ES6410 (6K)	462	19
44315318	Toner OKI Magenta ES6410 (6K)	462	19
44315319	Toner OKI Cyan ES6410 (6K)	462	19
44315320	Toner OKI Noir ES6410 (8K)	203	19
44315321	Toner OKI Jaune C610 (6K)	774	19
44315322	Toner OKI Magenta C610 (6K)	774	19
44315323	Toner OKI Cyan C610 (6K)	774	19
44315324	Toner OKI Noir C610 (8K)	464	19
44318505	Tambour OKI Jaune C711-ES7411DME (20K)	624	19
44318506	Tambour OKI Magenta C711-ES7411DME (20K)	624	19
44318507	Tambour OKI Cyan C711-ES7411DME (20K)	624	19
44318508	Tambour OKI Noir C711-ES7411DME (20K)	307	19
44318529	Tambour OKI Blanc C711WT (6K)	928	19

44318605	Toner OKI Jaune C710-C711 (11.5K)	947	19
44318606	Toner OKI Magenta C710-C711 (11.5K)	948	19
44318607	Toner OKI Cyan C710-C711 (11.5K)	947	19
44318608	Toner OKI Noir C710-C711 (11K)	526	19
44318621	Toner OKI Jaune C710-C711 (11.5K)	947	19
44318622	Toner OKI Magenta C710-C711 (11.5K)	948	19
44318623	Toner OKI Cyan C710-C711 (11.5K)	947	19
44318624	Toner OKI Noir C710-C711 (11K)	526	19
44318657	Toner OKI Blanc C711WT (6K)	1968	19
44318659	Toner OKI Blanc ES7411WT (6K)	1642	19
44469704	Toner OKI Jaune C310-C331-C510-C511-C531-MC561-MC562 (2K)	368	19
44469705	Toner OKI Magenta C310-C331-C510-C511-C531-MC561-MC562 (2K)	368	19
44469706	Toner OKI Cyan C310-C331-C510-C511-C531-MC561-MC562 (2K)	368	19
44469714	Toner OKI Jaune C310-C331-C510-C511-C531-MC562 (2K)	368	19
44469715	Toner OKI Magenta C310-C331-C510-C511-C531-MC561-MC562 (2K)	368	19
44469716	Toner OKI Cyan C310-C331-C510-C511-C531-MC561-MC562 (2K)	368	19
44469722	Toner OKI Jaune C510-C511-C531-MC561-MC562 (5K)	729	19
44469723	Toner OKI Magenta C510-C511-C531-MC561-MC562 (5K)	729	19
44469724	Toner OKI Cyan C510-C511-C531-MC561-MC562 (5K)	729	19
44469740	Toner OKI Jaune ES5430-ES3451-ES5461 (5K)	508	19
44469741	Toner OKI Magenta ES5430-ES3451-ES5461 (5K)	508	19
44469742	Toner OKI Cyan ES5430-ES3451-ES5461 (5K)	508	19
44469752	Toner OKI Jaune C510-C511-C531-MC561-MC562 (5K)	729	19
44469753	Toner OKI Magenta C510-C511-C531-MC561-MC562 (5K)	729	19
44469754	Toner OKI Cyan C510-C511-C531-MC561-MC562 (5K)	729	19
44469803	Toner OKI Noir C310-C331-C510-C511-C531-MC561-MC562 (3.5K)	253	19
44469804	Toner OKI Noir C510-C531-MC561-MC562 (5K)	335	19
44469809	Toner OKI Noir C310-C331-C510-C511-531-MC562 (3.5K)	253	19
44469810	Toner OKI Noir C510-C531-MC561-MC562 (5K)	335	19
44469814	Toner OKI Noir ES5430-ES3451-ES5461(5K)	130	19
44472603	Unité de Fusion OKI MC300-C301-C321-C310-C330-C331-C510-C530-C511 (60K)	336	19
44494202	Tambour OKI Pack de 4 Couleur C310-C331-C330-C510-C530-C511	650	19
44574302	Tambour OKI Noir B411-B431-B432-B412 (25K)	537	19

44574307	Tambour OKI B401-MB441-MB451 (25K)	461	19
44574702	Toner OKI B411-B431 (3K)	199	19
44574705	Toner OKI B411-B431 (3K)	199	19
44574802	Toner OKI B411-B431-MB491 (7K)	443	19
44574805	Toner OKI B411-B431-MB491 (7K)	443	19
44643001	Toner OKI Jaune C801-C821 (7.3K)	878	19
44643002	Toner OKI Magenta C801-C821 (7.3K)	878	19
44643003	Toner OKI Cyan C801-C821 (7.3K)	878	19
44643004	Toner OKI Noir C801-C821 (7K)	371	19
44643005	Toner OKI Jaune C801-C821 (7.3K)	878	19
44643006	Toner OKI Magenta C801-C821 (7.3K)	878	19
44643007	Toner OKI Cyan C801-C821 (7.3K)	878	19
44643008	Toner OKI Noir C801-C821 (7K)	371	19
44661802	Toner OKI B840 (20K)	965	19
44844469	Tambour OKI Jaune MC853-MC873-MC883 (30K)	722	19
44844470	Tambour OKI Magenta MC853-MC873-MC883 (30K)	722	19
44844471	Tambour OKI Cyan MC853-MC873-MC883 (30K)	722	19
44844472	Tambour OKI Noir MC853-MC873-MC883 (30K)	722	19
44844613	Toner OKI Jaune C822 (7.3K)	798	19
44844614	Toner OKI Magenta C822 (7.3K)	799	19
44844615	Toner OKI Cyan C822 (7.3K)	799	19
44844616	Toner OKI Noir C822 (7K)	390	19
44844625	Toner OKI Jaune C822 (7.3K)	798	19
44844626	Toner OKI Magenta C822 (7.3K)	799	19
44844627	Toner OKI Cyan C822 (7.3K)	799	19
44844628	Toner OKI Noir C822 (7K)	390	19
44917602	Toner OKI B431-MB491 (12K)	650	19
44917607	Toner OKI ES4131-ES4161-ES4191 (12K)	351	19
44917608	Toner OKI B431-MB491 (12K)	650	19
44947309	Toner OKI Jaune ES9460-ES9470 (32.1K)	810	19
44947310	Toner OKI Magenta ES9460-ES9470 (32.1K)	810	19
44947311	Toner OKI Cyan ES9460-ES9470 (32.1K)	810	19
44947312	Toner OKI Noir ES9460-ES9470 (41K)	429	19

44953401	Récupérateur de toner usagé ES9460-ES9470 (114K)	94	19
44954103	Staple OKI 3100 Saddlestitch ES9460-ES9470 (4 X 2000 Staples)	491	19
44957901	Développeur OKI Jaune ES9460-ES9470 (187K)	1452	19
44957902	Développeur OKI Magenta ES9460-ES9470 (187K)	1452	19
44957903	Développeur OKI Cyan ES9460-ES9470 (187K)	1452	19
44957904	Développeur OKI Noir ES9460-ES9470 (187K)	261	19
44958001	Tambour OKI Pack de 4 Couleur ES9460-ES9470 (77K)	175	19
44968301	Tambour OKI C301-C321-C331-C511-C531 (20K)	620	19
44973508	Toner OKI Noir C511-C531-MC562 (7K)	335	19
44973509	Toner OKI Jaune ES5431-ES3452-ES5462 (6K)	583	19
44973510	Toner OKI Magenta ES5431-ES3452-ES5462 (6K)	583	19
44973511	Toner OKI Cyan ES5431-ES3452-ES5462 (6K)	583	19
44973512	Toner OKI Noir ES5431-ES3452-ES5462 (7K)	172	19
44973533	Toner OKI Jaune C301-C321-MC332-MC342 (1.5K)	371	19
44973534	Toner OKI Magenta C301-C321-MC332-MC342 (1.5K)	371	19
44973535	Toner OKI Cyan C301-C321-MC332-MC342 (1.5K)	371	19
44973536	Toner OKI Noir C301-C321-MC332-MC342 (2.2K)	315	19
44973540	Toner OKI Noir C511-C531-MC562 (7K)	335	19
44973541	Toner OKI Jaune C301-C321-MC332-MC342 (1.5K)	371	19
44973542	Toner OKI Magenta C301-C321-MC332-MC342 (1.5K)	371	19
44973543	Toner OKI Cyan C301-C321-MC332-MC342 (1.5K)	371	19
44973544	Toner OKI Noir C301-C321-MC332-MC342 (2.2K)	315	19
44992401	Toner OKI B401-MB441-MB451 (1.5K)	177	19
44992402	Toner OKI B401-MB441-MB451 (2.5K)	247	19
44992403	Toner OKI B401-MB441-MB451 (1.5K)	177	19
44992404	Toner OKI B401-MB441-MB451 (2.5K)	247	19
45008802	Toner OKI Noir ES9160-ES9170 (44K)	395	19
45008901	Développeur OKI ES9160-ES9170 (125K)	643	19
45009001	Tambour OKI ES9160-ES9170 (56K)	544	19
45103713	Tambour OKI Jaune C911-C931 (40K)	2223	19
45103714	Tambour OKI Magenta C911-C931 (40K)	2223	19
45103715	Tambour OKI Cyan C911-C931 (40K)	2223	19
45103716	Tambour OKI Noir C911-C931 (40K)	1365	19

45103719	Tambour OKI Jaune ES9431-ES9541-Pro9542 (40K)	1468	19
45103720	Tambour OKI Magenta ES9431-ES9541-Pro9542 (40K)	1468	19
45103721	Tambour OKI Cyan ES9431-ES9541-Pro9542 (40K)	1468	19
45103722	Tambour OKI Noir ES9431-ES9541-Pro9542 (40K)	826	19
45103723	Tambour OKI Blanc ES9541 (20K)	752	19
45103724	Tambour OKI Clair ES9541 (20K)	752	19
45103765	Tambour OKI Blanc Pro9542 (20K)	752	19
45395701	Tambour OKI Jaune MC760-MC770-MC780 (30K)	985	19
45395702	Tambour OKI Jaune MC760-MC770-MC780 (30K)	985	19
45395703	Tambour OKI Cyan MC760-MC770-MC780 (30K)	985	19
45395704	Tambour OKI Noir MC760-MC770-MC780 (30K)	562	19
45396201	Toner OKI Jaune MC770-MC780 (11.5K)	653	19
45396202	Toner OKI Magenta MC770-MC780 (11.5K)	653	19
45396203	Toner OKI Cyan MC770-MC780 (11.5K)	660	19
45396204	Toner OKI Noir MC770-MC780 (15K)	502	19
45396213	Toner OKI Jaune ES7460-ES7480 (11.5K)	430	19
45396214	Toner OKI Magenta ES7460-ES7480 (11.5K)	430	19
45396215	Toner OKI Cyan ES7460-ES7480 (11.5K)	430	19
45396216	Toner OKI Noir ES7460-ES7480 (15K)	174	19
45396301	Toner OKI Jaune MC760-MC770-MC780 (6K)	580	19
45396302	Toner OKI Magenta MC760-MC770-MC780 (6K)	579	19
45396303	Toner OKI Cyan MC760-MC770-MC780 (6K)	580	19
45396304	Toner OKI Noir MC760-MC770-MC780 (8K)	400	19
45439002	Toner OKI B731-MB770 (36K)	1189	19
45456302	Tambour OKI Noir ES7131 (72K)	601	19
45460502	Toner OKI Noir ES7131 (36K)	570	19
45488802	Toner OKI B731-MB760-MB770 (18K)	951	19
45531113	Unité de Fusion OKI Pro9541-Pro9542-C931 (150K)	1041	19
45531223	Transfer Belt OKI Pro9541-Pro9542 (150K)	946	19
45531503	Récupérateur du toner usagé C931-ES9431-Pro9542 (40K)	92	19
45536413	Toner OKI Jaune C911-C931 (24K)	1358	19
45536414	Toner OKI Magenta C911-C931 (24K)	1357	19
45536415	Toner OKI Cyan C911-C931 (24K)	1357	19

45536416	Toner OKI Noir C911-C931 (24K)	681	19
45536425	Toner OKI Blanc ES9541 (10K)	829	19
45536428	Toner OKI Clair ES9541 (20K)	1337	19
45536437	Toner OKI Jaune Pro9542 (24K)	359	19
45536471	Toner OKI Jaune Pro9541WT (24K)	593	19
45536472	Toner OKI Magenta Pro9541WT (24K)	593	19
45536473	Toner OKI Cyan Pro9541WT (24K)	593	19
45536474	Toner OKI Noir Pro9541WT (24K)	413	19
45536475	Toner OKI Blanc Pro9541WT (10K)	954	19
45536505	Toner OKI Jaune C931(38K)	1734	19
45536506	Toner OKI Magenta C931(38K)	1734	19
45536507	Toner OKI Cyan C931(38K)	1734	19
45536508	Toner OKI Noir C931(38K)	832	19
45536509	Toner OKI Jaune ES9431-ES9541 (38K)	799	19
45536510	Toner OKI Magenta ES9431-ES9541 (38K)	799	19
45536511	Toner OKI Cyan ES9431-ES9541 (38K)	799	19
45536512	Toner OKI Noir ES9431-ES9541 (38K)	771	19
45536543	Toner OKI Blanc Pro9542 (15K)	1181	19
45536553	Toner OKI Jaune Pro9431-Pro9541-Pro9542 (42K)	627	19
45536554	Toner OKI Magenta Pro9431-Pro9541-Pro9542 (42K)	627	19
45536555	Toner OKI Cyan Pro9431-Pro9541-Pro9542 (42K)	627	19
45536556	Toner OKI Noir Pro9431-Pro9541-Pro9542 (51K)	770	19
45639501	Récupérateur de toner usagé ES9455 (14K-56K)	76	19
45643509	Toner OKI Jaune ES9465-ES9475 (33.6K)	458	19
45643510	Toner OKI Magenta ES9465-ES9475 (33.6K)	458	19
45643511	Toner OKI Cyan ES9465-ES9475 (33.6K)	458	19
45643512	Toner OKI Noir ES9465-ES9475 (38.4K)	309	19
45643609	Toner OKI Jaune ES9455 (33.6K)	715	19
45643610	Toner OKI Magenta ES9455 (33.6K)	715	19
45643611	Toner OKI Cyan ES9455 (33.6K)	715	19
45643612	Toner OKI Noir ES9455 (38.4K)	359	19
45643701	Développeur OKI Jaune ES9455-ES9465-ES9475 (33.6K)	1571	19
45643702	Développeur OKI Magenta ES9455-ES9465-ES9475 (33.6K)	1571	19

45643703	Développeur OKI Cyan ES9455-ES9465-ES9475 (33.6K)	1571	19
45643704	Développeur OKI Noir ES9455-ES9465-ES9475 (38.4K)	238	19
45643901	Tambour OKI ES9455 (210K)	496	19
45807102	Toner OKI B432-B412-MB492-MB472 (3K)	264	19
45807106	Toner OKI B432-B412-MB492-MB472 (7K)	324	19
45807111	Toner OKI B432-MB492-MB472 (12K)	443	19
45807116	Toner OKI ES4132-ES4192-ES5112-ES5162 (12K)	351	19
45807119	Toner OKI B432-B412-MB492-MB472 (3K)	264	19
45807120	Toner OKI B432-B412-MB492-MB472 (7K)	324	19
45807121	Toner OKI B432-MB492-MB472 (12K)	443	19
45862814	Toner OKI Jaune MC873-MC883 (10K)	744	19
45862815	Toner OKI Magenta MC873-MC883 (10K)	744	19
45862816	Toner OKI Cyan MC873-MC883 (10K)	744	19
45862818	Toner OKI Noir MC873-MC883 (15K)	528	19
45862837	Toner OKI Jaune MC873-MC853 (7.3K)	648	19
45862838	Toner OKI Magenta MC873-MC853 (7.3K)	647	19
45862839	Toner OKI Cyan MC873-MC853 (7.3K)	647	19
45862840	Toner OKI Noir MC873-MC853-MC883 (7K)	548	19
45862845	Toner OKI Jaune MC873-MC883 (10K)	744	19
45862846	Toner OKI Magenta MC873-MC883 (10K)	744	19
45862847	Toner OKI Cyan MC873-MC883 (10K)	744	19
45862848	Toner OKI Noir MC873-MC883 (15K)	528	19
45862849	Toner OKI Jaune MC873-MC853 (7.3K)	648	19
45862850	Toner OKI Magenta MC873-MC853 (7.3K)	647	19
45862851	Toner OKI Cyan MC873-MC853 (7.3K)	647	19
45862852	Toner OKI Jaune MC873-MC853-MC883 (7K)	548	19
45878117	Tambour OKI Blanc Pro8432WT (9K)	613	19
45878128	Tambour OKI Noir Pro8432WT (8.5K)	346	19
46298001	Toner OKI Jaune PRO6410 (6K)	1939	19
46298002	Toner OKI Magenta PRO6410 (6K)	1939	19
46298003	Toner OKI Cyan PRO6410 (6K)	1939	19
46298004	Toner OKI Blanc PRO6410 (4K)	1286	19
46298005	Toner OKI Noir PRO6410 (6K)	909	19

46394902	Transfer Belt OKI C532-MC573-ES5432-ES5473 (60K)	342	19
46438001	Tambour OKI Jaune C800 (30K)	490	19
46438002	Tambour OKI Magenta C800 (30K)	490	19
46438003	Tambour OKI Cyan C800 (30K)	490	19
46438004	Tambour OKI Noir C800 (30K)	490	19
46438013	Tambour OKI Jaune ES8433 (30K)	707	19
46438014	Tambour OKI Magenta ES8433 (30K)	707	19
46438015	Tambour OKI Cyan ES8433 (30K)	707	19
46438016	Tambour OKI Noir ES8433 (30K)	553	19
46443101	Toner OKI Jaune C833-C843 (10K)	819	19
46443102	Toner OKI Magenta C833-C843 (10K)	819	19
46443103	Toner OKI Cyan C833-C843 (10K)	819	19
46443104	Toner OKI Noir C833-C843 (10K)	337	19
46443113	Toner OKI Jaune C833-C843 (10K)	819	19
46443114	Toner OKI Magenta C833-C843 (10K)	819	19
46443115	Toner OKI Cyan C833-C843 (10K)	819	19
46443116	Toner OKI Noir C833-C843 (10K)	337	19
46443117	Toner OKI Jaune ES8433 (20K)	696	19
46443118	Toner OKI Magenta ES8433 (20K)	696	19
46443119	Toner OKI Cyan ES8433 (20K)	696	19
46443120	Toner OKI Noir ES8433 (20K)	391	19
46471101	Toner OKI Jaune C823-C833-C843 (7K)	1093	19
46471102	Toner OKI Magenta C823-C833-C843 (7K)	1093	19
46471103	Toner OKI Cyan C823-C833-C843 (7K)	1093	19
46471104	Toner OKI Noir C823-C833-C843 (7K)	481	19
46471105	Toner OKI Jaune C823-C833-C843 (7K)	1093	19
46471106	Toner OKI Magenta C823-C833-C843 (7K)	1093	19
46471107	Toner OKI Cyan C823-C833-C843 (7K)	1093	19
46471108	Toner OKI Noir C823-C833-C843 (7K)	481	19
46484105	Tambour OKI Jaune C532-MC573 (30K)	225	19
46484106	Tambour OKI Magenta C532-MC573 (30K)	225	19
46484107	Tambour OKI Cyan C532-MC573 (30K)	225	19
46484108	Tambour OKI Noir C532-MC573 (30K)	225	19

46484121	Tambour OKI Jaune ES5432-ES5473 (30K)	217	19
46484122	Tambour OKI Magenta ES5432-ES5473 (30K)	217	19
46484123	Tambour OKI Cyan ES5432-ES5473 (30K)	217	19
46484124	Tambour OKI Noir ES5432-ES5473 (30K)	217	19
46490401	Toner OKI Jaune C532-MC573 (1.5K)	308	19
46490402	Toner OKI Magenta C532-MC573 (1.5K)	308	19
46490403	Toner OKI Cyan C532-MC573 (1.5K)	308	19
46490404	Toner OKI Noir C532-MC573 (1.5K)	136	19
46490405	Toner OKI Jaune C532-MC573 (1.5K)	308	19
46490406	Toner OKI Magenta C532-MC573 (1.5K)	308	19
46490407	Toner OKI Cyan C532-MC573 (1.5K)	308	19
46490408	Toner OKI Noir C532-MC573 (1.5K)	136	19
46490605	Toner OKI Jaune C532-MC573 (6K)	965	19
46490606	Toner OKI Magenta C532-MC573 (6K)	926	19
46490607	Toner OKI Cyan C532-MC573 (6K)	965	19
46490608	Toner OKI Noir C532-MC573 (7K)	521	19
46490621	Toner OKI Jaune ES5432-ES5473 (6K)	505	19
46490622	Toner OKI Magenta ES5432-ES5473 (6K)	505	19
46490623	Toner OKI Cyan ES5432-ES5473 (6K)	505	19
46490624	Toner OKI Noir ES5432-ES5473 (7K)	247	19
46490629	Toner OKI Jaune C532-MC573 (6K)	965	19
46490630	Toner OKI Magenta C532-MC573 (6K)	965	19
46490631	Toner OKI Cyan C532-MC573 (6K)	965	19
46490632	Toner OKI Noir C532-MC573 (7K)	521	19
46507305	Tambour OKI Jaune C612 (30K)	455	19
46507306	Tambour OKI Magenta C612 (30K)	455	19
46507307	Tambour OKI Cyan C612 (30K)	455	19
46507308	Tambour OKI Noir C612 (30K)	318	19
46507313	Tambour OKI Jaune ES6412 (30K)	417	19
46507314	Tambour OKI Magenta ES6412 (30K)	391	19
46507315	Tambour OKI Cyan ES6412 (30K)	417	19
46507316	Tambour OKI Noir ES6412 (30K)	229	19
46507413	Tambour OKI Jaune C712 (30K)	406	19

46507414	Tambour OKI Magenta C712 (30K)	406	19
46507415	Tambour OKI Cyan C712 (30K)	406	19
46507416	Tambour OKI Noir C712 (30K)	307	19
46507417	Tambour OKI Jaune ES7412 (30K)	388	19
46507418	Tambour OKI Magenta ES7412 (30K)	392	19
46507419	Tambour OKI Cyan ES7412 (30K)	392	19
46507420	Tambour OKI Noir ES7412 (30K)	238	19
46507505	Toner OKI Jaune C612 (6K)	856	19
46507506	Toner OKI Magenta C612 (6K)	856	19
46507507	Toner OKI Cyan C612 (6K)	856	19
46507508	Toner OKI Noir C612 (8K)	427	19
46507513	Toner OKI Jaune ES6412 (6K)	466	19
46507514	Toner OKI Magenta ES6412 (6K)	466	19
46507515	Toner OKI Cyan ES6412 (6K)	466	19
46507516	Toner OKI Noir ES6412 (8K)	211	19
46507517	Toner OKI Jaune C612 (6K)	856	19
46507518	Toner OKI Magenta C612 (6K)	856	19
46507519	Toner OKI Cyan C612 (6K)	856	19
46507520	Toner OKI Noir C612 (8K)	427	19
46507613	Toner OKI Jaune C712 (11.5K)	920	19
46507614	Toner OKI Magenta C712 (11.5K)	920	19
46507615	Toner OKI Cyan C712 (11.5K)	920	19
46507616	Toner OKI Noir C712 (11K)	262	19
46507621	Toner OKI Jaune ES7412 (11.5K)	668	19
46507622	Toner OKI Magenta ES7412 (11.5K)	668	19
46507623	Toner OKI Cyan ES7412 (11.5K)	668	19
46507624	Toner OKI Noir ES7412 (11K)	188	19
46507625	Toner OKI Jaune C712 (11.5K)	920	19
46507626	Toner OKI Magenta C712 (11.5K)	920	19
46507627	Toner OKI Cyan C712 (11.5K)	920	19
46507628	Toner OKI Noir C712 (11K)	262	19
46508709	Toner OKI Jaune C332-MC363 (3K)	618	19
46508710	Toner OKI Magenta C332-MC363 (3K)	618	19

46508711	Toner OKI Cyan C332-MC363 (3K)	618	19
46508712	Toner OKI Noir C332-MC363 (3.5K)	308	19
46508713	Toner OKI Jaune C332-MC363 (1.5K)	378	19
46508714	Toner OKI Magenta C332-MC363 (1.5K)	378	19
46508715	Toner OKI Cyan C332-MC363 (1.5K)	378	19
46508716	Toner OKI Noir C332-MC363 (1.5K)	247	19
46508733	Toner OKI Jaune C332-MC363 (3K)	618	19
46508734	Toner OKI Magenta C332-MC363 (3K)	618	19
46508735	Toner OKI Cyan C332-MC363 (3K)	618	19
46508736	Toner OKI Noir C332-MC363 (3.5K)	308	19
46508737	Toner OKI Jaune C332-MC363 (1.5K)	378	19
46508738	Toner OKI Magenta C332-MC363 (1.5K)	378	19
46508739	Toner OKI Cyan C332-MC363 (1.5K)	378	19
46508740	Toner OKI Noir C332-MC363 (1.5K)	247	19
46606505	Toner OKI Jaune Pro8432WT (8.8K)	591	19
46606506	Toner OKI Magenta Pro8432WT (8.8K)	591	19
46606507	Toner OKI Cyan Pro8432WT (8.8K)	599	19
46606508	Toner OKI Blanc Pro8432WT (4.5K)	742	19
46606518	Toner OKI Noir Pro8432WT (8.5K)	296	19
46672305	Transfer Belt OKI Pro1040-Pro1050 (150K)	871	19
46672402	Récupérateur de toner usagé Pro1040-Pro1050 (50K)	139	19
46672506	Unité de Fusion OKI Pro1040-Pro1050 (150K)	1566	19
46844011	Toner + Tambour OKI Jaune Pro1040-Pro1050 (9K)	673	19
46844012	Toner + Tambour OKI Magenta Pro1040-Pro1050 (9K)	673	19
46844013	Toner + Tambour OKI Cyan Pro1040-Pro1050 (9K)	673	19
46844014	Toner + Tambour OKI Noir Pro1040-Pro1050 (9K)	673	19
46844015	Toner + Tambour OKI Blanc Pro1040-Pro1050 (4.5K)	1009	19
46857505	Tambour OKI Jaune C824-C834-C844 (30K)	490	19
46857506	Tambour OKI Magenta C824-C834-C844 (30K)	490	19
46857507	Tambour OKI Cyan C824-C834-C844 (30K)	490	19
46857508	Tambour OKI Noir C824-C834-C844 (30K)	490	19
46857521	Tambour OKI Jaune ES8434 (30K)	973	19
46857522	Tambour OKI Magenta ES8434 (30K)	973	19

46857523	Tambour OKI Cyan ES8434 (30K)	973	19
46857524	Tambour OKI Noir ES8434 (30K)	761	19
46861305	Toner OKI Jaune C834-C844 (10K)	819	19
46861306	Toner OKI Magenta C834-C844 (10K)	819	19
46861307	Toner OKI Cyan C834-C844 (10K)	819	19
46861308	Toner OKI Noir C834-C844 (10K)	337	19
46861321	Toner OKI Jaune C834-C844 (10K)	819	19
46861322	Toner OKI Magenta C834-C844 (10K)	819	19
46861323	Toner OKI Cyan C834-C844 (10K)	819	19
46861324	Toner OKI Noir C834-C844 (10K)	337	19
46861325	Toner OKI Jaune ES8434 (10K)	957	19
46861326	Toner OKI Magenta ES8434 (10K)	957	19
46861327	Toner OKI Cyan ES8434 (10K)	957	19
46861328	Toner OKI Noir ES8434 (10K)	531	19
47094106	Tambour OKI Jaune Pro9541WT (40K)	692	19
47094107	Tambour OKI Magenta Pro9541WT (40K)	692	19
47094108	Tambour OKI Cyan Pro9541WT (40K)	692	19
47094109	Tambour OKI Noir Pro9541WT (40K)	692	19
47094110	Tambour OKI Blanc Pro9541WT (20K)	777	19
47095701	Toner OKI Jaune C824-C834-C844 (5K)	713	19
47095702	Toner OKI Magenta C824-C834-C844 (5K)	713	19
47095703	Toner OKI Cyan C824-C834-C844 (5K)	713	19
47095704	Toner OKI Noir C824-C834-C844 (5K)	316	19
47095705	Toner OKI Jaune C824-C834-C844 (5K)	713	19
47095706	Toner OKI Magenta C824-C834-C844 (5K)	713	19
47095707	Toner OKI Cyan C824-C834-C844 (5K)	713	19
47095708	Toner OKI Noir C824-C834-C844 (5K)	316	19

RUBANS OKI

Référence	Désignation	Prix Partenaire	TVA %
1126302	Ruban OKI ML5500-ML5520--ML5521-ML5590-ML5591 (4M Caractères)	84	19
9002303	Ruban OKI ML332x-ML18x-ML19x-ML280-ML32x (3M Caractères)	48	19
9002308	Ruban OKI ML3410 (7M Caractères)	218	19
9002309	Ruban OKI ML339x-ML38x-ML39x (2M Caractères)	66	19

9002311	Ruban OKI ML395-ML393 (5M Caractères)	192	19
9005591	Ruban OKI MX 8000 (17k)	330	19
9005660	Ruban OKI MX8000 Pack de 4 (30K)	1530	19
40629303	Ruban OKI ML4410 (15M Caractères)	248	19
43503601	Ruban OKI ML6300FB (4M Caractères)	88	19
43571802	Ruban OKI ML1120-ML1190 (4M Caractères)	32	19
43821103	Ruban OKI ML5100 FB (2M Caractères)	54	19
44173405	Ruban OKI ML5720-ML5790 (8M Caractères)	56	19
44173406	Ruban OKI ML5721-ML5791 (13M Caractères)	84	19

Adresse: 14, Rue Ahmed Rami (par Alain Savary) 1002 Tunis - Tunisie

Mail: commercial@tunigros.com

Tel: (+216) 71 280 447 / (+216) 71 282 043

Fax: (+216) 71 791 876

Vos contacts :

Direct Mr Taoufik Chibani: 70 168 665 / Direct Mr Wassim Dhiab: 70 168 666

